

# ATL

# DRYING OUT

## AQUI-FER™ & AQUA-FLEX®

### WATER BLADDERS PRIOR TO STORAGE OR SHIPPING

Typical Dry-Out Procedure Shown Below:



Run For 2 Hours Per 100 Gallon  
(400 Liters) of Capacity.

#### ATL World Headquarters

Aero Tec Laboratories Inc.  
45 Spear Road Corporate Park  
Ramsey, New Jersey 07446-1251 USA  
Tel: +1-201-825-1400 • Fax: +1-201-825-1962  
Email: atl@atllnc.com • Web: atllnc.com

#### ATL European Operations

Aero Tec Laboratories Ltd.  
ATL Technology Centre, Denbigh Road  
Bletchley, Milton Keynes, MK1 1DF England  
Tel: +44 (0) 1908-351700 • Fax: +44 (0) 1908-351750  
Email: atl@atlltd.com • Web: atlltd.com

ATL

DS-653  
1X17